



Stomp the light to Win Tickets!!



How to Play

1. Stand on the "STOP" button and insert coin(s).
2. The light will move towards you. When the light reaches the "STOP" button, "Jump and stomp the light."
3. You will win ticket(s) when you succeed in stopping the light at the "STOP" button
4. Get ready for the next round. The light will move faster!!
5. To get the "Jackpot Challenge" you will have to win 5 consecutive rounds.

Specification

Size: (H) 93" x (W) 53" x (D) 87"

Weight: 474 lbs.

Power: Maximum current

220W, 2.8A

Specification subject to change without notice



©SEGA. SEGA is registered in the U.S. Patent and Trademark Office. SEGA and the SEGA logo are either registered trademarks or trademarks of SEGA Corporation.

© 2008 Viacom International Inc. All Rights Reserved.

Nickelodeon, SpongeBob SquarePants and all related titles, logos and characters are trademarks of Viacom International Inc.

Stephen Hillenburg



FOR MORE INFORMATION, CONTACT PRIMETIME AMUSEMENTS: 1.800.550.0900 PRIMETIMEAMUSEMENTS.COM

VISIT US AT: [HTTP://PRIMETIMEAMUSEMENTS.COM](http://PRIMETIMEAMUSEMENTS.COM)