



Enter the newest, most realistic, 3-dimensional "Gradius" world!

Choose the manual power-up option to create your own power-up weapon configuration.





JOYSTICK/THE SPLASHING LASER
Use the joystick to control your ship, press the shot button for missiles and pull the trigger to fire the loser.

Collect the laser icon to get the "splashing laser". To energize the splashing laser, hold down both the trigger and the missile button. Release the trigger or button to fire this special attack. The langer you energize, the stronger the laser becomes.

SELECTING THE VIEWS

Select from two different views: the dynamic, close-up view or the distant, easy control view.

SELECTING A POWER-UP SYSTEM Choose the manual power-up option to create your own power-up weapon configuration.

29-INCH COLOR MONITOR

ALSO AVAILABLE AS COMPACT 29" SITDOWN









BRITISH

SPECIFICATIONS

Dimensions

Total Wt. Monitor

W:33.8 in D: 60.4 in H: 71.7 in Approximately 425.6 lb 29-inch color monitor

SOLAR ASSAULT ™ and KONAMI ® are trademarks of KONAMI CO., LTD. ©1997 KONAMI ALL RIGHTS RESERVED.



KONAMI OF AMERICA, INC. 900 DEERFIELD PARKWAY BUFFALO GROVE, IL 60089 847-215-5100 FAX 847-215-5122